



AZ Instrument Corp.

Web site: <http://www.az-instrument.com.tw>
E-mail: info@az-instrument.com.tw

Tel: 886-4-25326668 (rep.)
Fax: 886-4-25326593

Edit by Mari Weng 13 Jan. 2021

How to turn on LCD while my 88597, 88598 or 88599 datalogger is in logging mode

Answer:

The LCD is off during logging mode for power saving.

To turn LCD on, just **press "MAX/MIN" key once** to turn the LCD on, no need to press long. Press again, the LCD will be turned off but the recording remains.