

Edit by Naima 6th Jan. 2021

Why can't I disable auto power off after press HOLD & SET Key?

To disable auto power off, please press HOLD & SET key for around 2 second when meter is off, see below image:

