

Edit by Naima 29 Apr. 2020

## Question

**Can 8928 be connecting to a computer?**

## Reply:

For 8928 sound level meter, please note that only analog output is available.

A 3.5mm phono output jack is available for connection to external test equipment.



An AC rms voltage is provided (0.707V maximum) which is a linearized representation of the analog pointer reading.

You can connect this output to a datalogger, chart recorder, etc. for datalogging purposes.