

Q: For 8816X and 8826X PDF USB dataloggers, how to make the reading update faster on LCD even I program the sampling rate as every 30 mins?

Edit: Mari Weng 3/18, 2024

Answer:

The LCD update rate equals to the sampling rate you setup. However, if frequent battery replacement is not a concern for you, you may change the alarm mode to “**cumulative**” so the LCD will update every 10 seconds regardless the sampling rate you entered.