



**AZ Instrument Corp.**

Web site: <http://www.az-instrument.com.tw>  
E-mail: [info@az-instrument.com.tw](mailto:info@az-instrument.com.tw)

Tel: 886-4-25326668 (rep.)  
Fax: 886-4-25326593

---

Edit by Naima 30 Dec. 2019

### **Question**

**8808 user manual does not include the steps to configure the speaker when the alarm is adjusted, would you please advise?**

Reply:

The alarm setting will also synchronize the buzzer alarm, if user didn't hear the audio alarm when it's exceed the alarm range, the reason might be the power supply isn't sufficient.

Please change new battery or use 9V adaptor for full power supply.