



AZ Instrument Corp.

Web site: <http://www.az-instrument.com.tw>
E-mail: info@az-instrument.com.tw

Tel: 886-4-25326668 (rep.)
Fax: 886-4-25326593

Edit by Naima 6 Feb. 2020

Question

What to do when my ORP pen is in big deviation?

Reply:

We suggest to do “**ORP electrode cleaning**” & “**Test the electrode**” according to the user manual chapter.

For the ratio of mentioned test solution, it's

“50ml of pH 4 + 1g of quinhydrone”,

“50ml of pH 7 + 1g of quinhydrone”,

and it need to be used within one hour after mixed.

If it still not working, please contact with the local shop you purchase this product with serial number and related information for after service.