



**AZ Instrument Corp.**

Web site: <http://www.az-instrument.com.tw>  
E-mail: [info@az-instrument.com.tw](mailto:info@az-instrument.com.tw)

Tel: 886-4-25326668 (rep.)  
Fax: 886-4-25326593

---

Edit by Naima 25 Feb. 2021

### **Question**

Why 87786 heat stress meter does not log anymore?

### **Reply:**

If user want to start another logging again, they will have to download the data first before re-start the logging.

It's the design to prevent the recorded data to be overwritten without download.

Here is an operation video for your further reference:

<https://www.youtube.com/watch?v=5aDS0r-Tk38&t=242s>