

By Mari Weng. 2020/6/30

## FAQ

Why my multiple use datalogger could not record second time?

Hello, is this recorder designed one time recording only?

We've used a device (AZ 88163 S/N:1901770) for recording our warehouse temperature. Started recording on 5/12, stopped on 6/2, we can see the recorded data by pdf and csv, but it can not reset to start another recording....

## ANSWER:

#88163 is designed for multiple time use. After you download the data, please go back to **configure** page to **re-check all the setting and then press SAVE to confirm.**

Then, once you long press the start key again to record, you will see green LED blink to start recording and the new record will overwrite the kept old data in the logger memory IC.