



Edit by Naima 30 June 2020

Question

Can AZ96315 pressure datalogger do real time output?

Reply:

AZ96315 pressure datalogger is with auto logging function, it can measure and store the data according to pre-set parameters, the recorded data will includes the setting date & time, which can be download and viewed on compatible software afterward.

The design principle for this type of datalogging series is for user to bring the meter around to log the measurement at certain place, in certain period of time, and the recorded data can be downloaded afterward, therefore, please understand that the real time data output in this series is not available.

For real time out put manometer, we have model #82152 which works with #VZUSBAZM USB cable and software kit.

This model is with 99 points manual logging function, the manual logging data can be viewed on meter, but can't be output.

Nevertheless, when it connected with PC / laptop with #VZUSBAZM USB cable and software kit, it can do real time output, below is the link of more production information for your reference.

<https://www.az-instrument.com.tw/en/product-616450/15-PSI-Manometer-82152-AZ.html>