



Edit by Naima 3 Mar. 2020

Question

Can I set up my 8403 into non-sleep mode?

Reply:

The measuring principle of #8403 DO probe will consume oxygen gradually of your testing sample, therefore, the default setting is that meter will turn off automatically after power on by 120 mins.

Here is a RD testing function key that we didn't disclosure on manual, but you may try.

1. Turn off the device first.
2. Press **POWER** and **HOLD** key at the same time to power on the device.
3. **nSL** (non sleep) will shown on display, then released keys.

Now, you are in non-sleep mode and the meter won't turn off even after 120 mins.