



**AZ Instrument Corp.**

No.3-2, Jianguo Rd., Tanzi Dist., Taichung City 427, Taiwan R.O.C

Web site: <http://www.az-instrument.com.tw>

E-mail: [info@az-instrument.com.tw](mailto:info@az-instrument.com.tw)

衡欣實業股份有限公司

台中縣潭子鄉建國路 3-2 號

Tel: 886-4-25326668 (rep.)

Fax: 886-4-25326593

---

Edit by Livia 20 Feb. 2020

Question:

Our customer needs liquid at the end of the probe 8601  
what liquid can we infuse?

Reply:

Our standard formula is 4M KCL+pH4 buffer in 1:1 ratio.

But if you could not mix formulae by your side, you could try to find other commercial pH probe storage solution with 3M KCl. Or use the pH 4 or pH7 calibration buffer to keep the probe wet.

Welcome to refer more information about the pH probe storage & refill from the following linkage,

<https://www.coleparmer.com/tech-article/ph-electrode-care>