



**AZ Instrument Corp.**

Web site: <http://www.az-instrument.com.tw>  
E-mail: [info@az-instrument.com.tw](mailto:info@az-instrument.com.tw)

Tel: 886-4-25326668 (rep.)  
Fax: 886-4-25326593

---

Edit by Naima 30 Dec. 2019

## **Question**

**How's the relay on #7722 CO2 monitor work?**

## **Reply:**

The relay build in #7722 CO2 is quite small, it can only drive a small device. The specification of #7722 relay is **1A 30VDC/0.5A 125VAC** for your reference.

To drive on a bigger fan or ventilation system, it must have another bigger relay in between to control power on/off.