

Wet Bulb Dry Bulb Hygrometer 8760/87601/8762



8762



87601



8760

- Excellent for green house, high humidity, harsh & dusty environment. Condensation caused by water/ pesticide/ fertilizer spray and dust scrap have very limited effect on humidity reading.
- Designed with two thermistor sensors to get accurate & quick temperature & humidity reading by using dry bulb & wet bulb principle
- Built-in fan to speed up the response time to 2 mins
- Dual color LED indicator for logging and alarm
- Humidity self-calibration is not required



Metric/Imperial



MAX/MIN



Auto Logging



Memory Recall



Low Battery



LED Alarm



PC Link



Relay



Model	8762	8760	87601
Temp. range	5~50°C		
Temp. resolution	0.1°C/°F		
Temp. accuracy	+/-0.6°C		
Humidity. range	0.1%RH~99.9%RH		
Humidity resolution	0.1%RH		
Humidity accuracy	+/-3%(10~100%RH@25°C), the rest is +/-5%		
Response time	120 seconds typical		
LCD size (mm)	25(H)x40(W)		
Memory	100 points	100 points	16000 points
PC download	NO, manually recall	NO, manually recall	YES
Relay	YES	NO	NO
Operation temp.	5~50°C		
Operation RH%	Humidity < 100%		
Storage temp.	0~50°C		
Storage RH%	Humidity < 80%		
Water Tank Refill Time	Every two weeks		
Dimension(mm)	48.4x178.5x24.7(H)		
Weight	~250g		
Battery	AAA x 4pcs or 5V adaptor		
Standard Package	Meter/Water tank/ Battery/Manual/Paper box /Cotton thread		
Optional Package	5V universal adaptor software cable & CD (87601 only)		

Ordering Code

Bulk order only

- VZ8762AZ, 8762 hygrometer
- VZ87601AZ, 87601 hygrometer
- V8760AZ, 8760 hygrometer
- VZ12405AZ, 5V universal adaptor
- VZUSBNLD, software kit w/USB cable for 87601
- VW38819A, a relay output wire for 8762



Power with relay or PC port

Hanger

Water Tank



Side View

